

Technical specs

M9300 - M9300 - STRAP GALAXY

Name:

RESPIRATORY FULL FACE MASK - STRAP ADJUSTMENT

Size:

Adjustable

Colour:

Black / Blue



CE 0082

Description :

Silicone full face mask with strap adjustment. Wide polycarbonate screen (210°). Inside silicone half-mask to reduce mist and increase comfort (3 inhalation valves, an exhalation valve, phonic system). Adjustable size. Shoulder strap to hold the mask when not in use. Compatible with EN148-1 type cartridges M9000 range, sold separately. Storage bag included

Strong points:

Silicone fixing straps.
Wide vision (210°).

Instructions for use:

The respiratory protection devices STRAP GALAXY M9300 is designed to comply with the standard EN136:1998 Class 3. They are robust and offer considerable resistance to radiant heat and flames. These masks are fitted with a standard threaded joint. They should be used with respiratory devices fitted with a male joint compliant with standard EN148-1 (standard threaded joint): Examples: anti-gas filters, filters against solid and liquid particles, combined filters to standard EN14387 (anti-gas filters and combined filters). We recommend using cartridges EN148-1 M8000 & M9000 series available in A2, ABEK2, ABEK2P3, A2P3 and P3 (see the specific user manuals for these devices).

Limits to use:

- Do not use for any purpose other than that defined above;
- DELTA PLUS shall not be held liable in the event of improper use or incorrect maintenance of this equipment;
- These masks should be used by qualified and trained personnel. These people should remain under the surveillance and responsibility of management perfectly aware of the limits of use and the laws in force in the country of use;
- These masks should not be used with positive pressure respiratory devices;
- These masks should not be used with closed circuit oxygen respiratory devices;
- It is unlikely that sealing requirements be met if beard hair or glasses pass under the airtight surface;
- Enriched oxygen poses a very high risk of fire or explosion. Take this into consideration when selecting your equipment;
- These masks can only be worn with their filtration system in atmospheres where the oxygen concentration is > 18%;
- Do not use this respiratory protection device in potentially explosive atmospheres;
- Before entering a contaminated area, you must check the sealing of the mask (see § Sealing inspection);
- These masks have been designed for use with certain items of personal protective equipment (hard hats, ear defenders). Check that using them simultaneously does not interfere with the level of protection of each item of equipment.

Instructions for storage:

Store in a cool, dry place, away from light, frost, dust, heat sources and chemical products. The masks should be stored at temperatures between 0°C and +40°C in their original packaging.

Instructions for cleaning / maintenance:

Clean and disinfect using warm soapy water or neutral detergent. Allow to dry freely in a non-contaminated atmosphere. Never use solvents, abrasive or noxious products. Special care should be paid to cleaning the valves. It is not recommended to fully dismantle the mask for further maintenance



DELTA PLUS GROUP

La Peyrolière - B.P. 140 - 84405 APT Cedex - France
www.deltaplus.fr



Technical specs

M9300 - M9300 - STRAP GALAXY

Performances :

This respiratory mask complies with the European Directive 89/686, notably regarding ergonomics, innocuousness, comfort, and with EN136:1998 standard